



# ECLIPSE 3135EC

## Calculating drawer box dimensions

<b>Formula for calculating outside drawer length</b>											
Slide length	12"	14"	15"	16"	18"	20"	21"	22"	24"	26"	28"
Outside drawer box length	12"	14"	15"	16"	18"	20"	21"	22"	24"	26"	28"
<b>Drawer box length tolerance is +0/ -1/16"</b>											
<b>Formula for calculating inside drawer width</b>											
For drawer side thickness	5/8"	16.00 mm	19/32"	15.00 mm	9/16"	14.00 mm	1/2"	13.00 mm			
Deduct from inside cabinet width	1-3/4"	44.45 mm	1-3/4"	44.45 mm	1-3/4"	44.45 mm	1-3/4"	44.45 mm			
<b>Formula for calculating outside drawer width</b>											
For drawer side thickness	5/8"	16.00 mm	19/32"	15.00 mm	9/16"	14.00 mm	1/2"	13.00 mm			
Deduct from inside cabinet width	1/2"	13.00 mm	9/16"	15.00 mm	5/8"	17.00 mm	3/4"	19.00 mm			

**Accuride®**